

# ALLEN & HEATH

## XB-14 CABLE COVER

Kit Part No: XB-14-COVER

## FITTING INSTRUCTIONS

AP7720

To fit cover, firstly remove the two M3x4 countersink screws located at top left and right of console. Place cover in position; fit using x4, M3x6 screws provided (as illustrated). Two screws are fitted at rear of console, remaining two screws fitted inside cover. These screws can be accessed through holes in top of cover.

